

PREPARING YOUR COMPRESSOR FOR WINTER

Install your compressor in a well-aerated cabinet located above the water level to prevent backflow and protect it from the elements. An electric fan in the cabinet will protect the compressor from overheating during the summer months.

If you are going to keep your compressor running all winter it must be kept entirely dry and well aerated; shelter it from the weather and any risk of flooding during the spring melt. Install in good view “Danger; thin ice” signs around your pond.

If you do not want to keep your compressor running all winter, it is essential to properly winterize it to prolong its life and to keep your warranty valid. You must:

- Unplug the compressor and ensure that there is no water in the supply lines
- Let it run empty, indoors, for a few minutes, to dry out the interior components of the compressor
- Place the compressor in a dry, warm area
- Re-install the compressor as soon as possible in the spring
- For linear models, you should clean the air filter with mild soap and water. For piston models you should change the air filter at the beginning of each season.
- Upon starting the system for a new season, we recommend a cleanup of the diffusers and airlines with Bio-Purge WD-3100.